


Typical adjustment of cleaning string



- The position of the cleaning string should be on the tip of the nozzle or overlapping for 0.5mm.